


Benchtop With Tray (Tall Sides)



Install the 5/16" lag bolt from the inside of the stand into the slot. This will give you plenty of flexibility. You can also reverse the arms for narrow fuselages.



Knobs go on the outside with 5/16" washers first. Adjust arms to about 1/2" to 1" from fuselage to minimize swaying.



I give you about 6 feet of Velcro One-Wrap for the straps, cut it at about 60% to 40% to make two straps. Straps just lay over Velcro arms and adjust accordingly.



Please don't hesitate to call if you have any questions at all.
RCPlaneStands.com

**PLEASE SEND ME A PHOTO WITH YOUR AIRCRAFT
ON IT SO I CAN POST IT ON MY WEBSITE.**

glen@rcplanestands.com

Glen (949) 633-3420